

# Bholanath

Precision Engineering Pvt.Ltd.

ISO 9001:2015



COMMITTED TO PRECISION  
www.bholanath.in

Made In India

## BH-SD Series(Absolute Encoder) AC Servo Driver Manual



### BH-130SM-ABS-2KW

Thank you for choosing SDD series servo driver. Please read this manual before using. The main contents of this manual include:

- \* Servo driver inspection, installation and wiring steps.
- \* Digital panel operation steps, status display, trouble alarm and disposal.
- \* Servo system control mode, trial running and adjustment steps.
- \* List of all the parameters of the servo drives.
- \* Servo drives specifications.

For daily inspection, maintenance, finding the exception reasons and countermeasures, please keep this manual for easy reference.

Note: Please give this manual to the end user so as to maximize the utility of the servo drives.

- The manual contents may be changed due to the product improvements, there will be no prior notice.

- Any changes made to the product by users, the company will not undertake any responsibility and the product warranty will be invalid.

When reading this manual, please pay special attention to the following warning signs



Indicates the wrong operation may cause disastrous consequences—death or serious injury!



Indicates the wrong operation may hurt the operator and also make damage to the equipment!



Indicates improper use may damage the product and equipment!

# Contents

## Chapter 1 Product inspection and installation

- 1.1 Product inspection..... 1-4
- 1.2 Servo driver specification..... 5
- 1.3 Servo driver installation..... 6-7

## Chapter 2 Servo driver and motor wiring

- 2.1 Servo drive power supply and periphery device wiring diagram... 8-9
- 2.2 Position control mode wiring diagram1..... 10
- 2.3 Position control mode wiring diagram2..... 11
- 2.4 Position control mode wiring diagram 3..... 12-14
- 2.5 Terminal electrical connection ..... 15-19
- 2.6 The principle diagram of single interference ..... 19-22

## Chapter 3 Operation and display

- 3.1 Keyboard operation..... 23-24
- 3.2 Monitoring approach..... 24-25
- 3.3 Parameter setting..... 26-27
- 3.4 Parameter management..... 27-29
- 3.5 F1 operation mode..... 30
- 3.6 F2 run mode..... 30-31
- 3.7 Others..... 31

## Chapter 4 Parameter

- 4.1 All parameters function and significance detail list..... 36-52
- 4.2 Parameter adjust diagram model..... 52
- 4.3 Servo key parameter description..... 53-54
- 4.4 Parameter adjust steps in actual application..... 54-55

## Chapter 5 Operation and debugging

- 5.1 Special attention items when debugging..... 56
- 5.2 Position control mode ..... 56-57
- 5.3 Speed run mode ..... 57
- 5.4 Jog operation..... 57-58
- 5.5 Internal position/speed/torque control mode..... 58-65
- 5.6 Servo function application..... 65-66
- 5.7 Simulation speed control mode..... 66

Chapter 1 Product inspection and installation 1

- 5.8 Simulation torque control mode..... 66
- 5.9 Position and simulation speed hybrid control mode..... 66
- 5.10 Position and simulation torque hybrid control mode..... 66

## Chapter 6 RS485 Communication

- 6.1 RS485 communication hardware interface..... 67
- 6.2 Communication protocol..... 68-72
- 6.3 Communication error and data processing..... 72
- 6.4 SDD series drive debugging software specification and usage .. 73-75
- 6.5 Communication command example..... 76-77




## Chapter 7 Alarm and disposal

- 7.1 Alarm list..... 78
- 7.2 Alarm process method..... 79-82
- 7.3 Common problems in use or exception handling..... 82-87


Appendix A SDD series drive and SM servo motor matching parameter list  
..... 88-90

Appendix B Product after-sales service explanation..... 91

# DIMENSIONS AND TECHNICAL DETAILS.



MOTOR MODEL	BH-130SM-2KW
Rated Power (KW)	2.0
Rated Voltage (V)	230
Rated Current (A)	7.5
Peak Current (A)	22.5
Rated Speed (RPM)	2500
Rated Torque (Nm)	7.7
Peak Torque (N.M )	22
Back emf(v/1000r/min)	68
Torque Coefficient (Nm/A)	1.03
Rotor Inertia (Kg.MP)	1.53X10 <sup>-3</sup>
Winding Resistance (Ω)	1.01
Winding Inductance (mH)	2.94
Electrical Time Constant(ms)	3.8
Weight (KG)	10
No of Encoder Lines (PPR)	17 Bit Absolute
Insulation Class	Class F(130 <sup>o</sup> c)
Safety Class	IP 65
Use Environment	Temperature; -20 <sup>o</sup> c to +40 <sup>o</sup> c, humidity; relative humidity<90%



**Motor Options Available -**  
 Standard Model - BH-130SM-ABS-2KW  
 With Low Backlash Planetary Gearbox - **PL**  
 With Electro Magnetic Brake - **BRK**  
 With Helical Gearbox - **HL**  
 CE Certificate - N - STANDARD/CE - CERTIFIED  
**ORDERING CODE - BH-130SM-ABS-2KW**



## Chapter 1 Product inspection and installation

### Summarize

BH-SD series servo is our third generation servo. All the input and output port can define itself, which is convenient to the user; standard RS485 communication function, realize uploads and downloads network control; internal simple PLC function, the PLC can be completely eliminated in some easy control occasions so as to lower the cost. Compare with the second generation SDB series servo, it has obvious improvement on the function and performance.

### 1.1 Product inspection

Our servo products have been done a completely functional test before leaving factory, in order to prevent the product exception in the process of shipment, please check the following items carefully when open the package:


1) Check the servo drive and motor model whether same as ordered. 2) Check the servo drive and motor appearance whether with damage or scratch. If there is any above mentioned defective or abnormal signs, please contact with local distributors immediately.

## Chapter 1 Product inspection and installation

### 1.1.2 SDD servo drive attached standard accessories

- ① CN1 plug(DB25 hole) 1 set
- ② CN2 plug(DB25 pin) 1 set
- ③ 5 pin power plug(SDD04NK7/SDD08NK8) 1 piece
- ④ 3 pin power plug(SDD04NK7/SDD08NK8) 1 piece
- ⑤ RS485 communication line(model CABLE01) 2 piece **optional**
- ⑥ Debugging communication line(model CABLE02) 1 piece **optional**


1.1.3 Servo drive installation size



Chapter 1 Product inspection and installation


**BH-SD servo drive installation dimensional**

**!!!!Notice: L N is 220V power supply , PD,C is external braking resistor terminals. It can not be connected wrong**



**servo drive installation dimensional**

**!!!!Notice: L N is 220V power supply, PD,C is external braking resistor terminals. It can not be connected wrong**



## 1.2 Servo drive specifications

Basic specifications	Model		BH-SD-ABS
	Maximum current(A)		18
	Power supply		single phase AC170~253V 50/60Hz
	Cooling method		Natural cooling/ fan Cooling
	Control method		SVPWM control
	Encoder		Provincial line or incremental encoder
	Internal functions	display and operation	
Control model		position control / speed trial run / jog run / internal positioning PLC function/RS485 communication/ speed/ torque	
Braking function		Internally installed	
Protection function		Under voltage, over voltage, over load, over current, encoder exception, braking, position error etc.	
Position control model	Command control model		External pulse
	External command pulse input	Form	pulse+ direction cw/ccw A/B orthogonality
		Maximum frequency	Differential motion:1MHZ open collector: 200KHZ
	Electronic gear ratio		$\frac{1}{32767}$ ~32767
	Speed control range		speed ratio: 1:5000
	Speed rate of change		Speed fluctuation ratio: $\leq \pm 0.03$ (load 0~100%) . $\leq \pm 0.05$ (power-15%~+10%)
	Command smooth way		Linear time constant 1ms 10000ms (0r/min $\longleftrightarrow$ 1000r/min)
	frequency characteristic		300HZ
input / output signal	location signal output	output type	ABZ phase line drive output/ Z open collector output
		Frequency division ratio	1/225~1Frequency division
	input signal	7 points photoelectric isolation input	Input point can be defined as any 21kinds, see parameter settings
	output signal	4 collector open	1) location/speed reach 2) servo alarm output 3) Z signal output 4) brake output. Freely defined
Usage temperature			Operation:0°C~55°C storage:-20°C~80°C

## Chapter 1 Product inspection and installation

6

### 1.3 Servo drive installation

#### 1.3.1 Installation environment conditions

Servo drive installation environment has a direct effect on the servo function and service life, therefore, the drive installation environment conditions must comply with following conditions:

Items	SDD servo drive
usage temperature/ humidity	0°C ~55°C (no frozen frost) 90%RH below (no condensation)
storage temperature/humidity	-20°C ~80°C 90%RH (no condensation)
atmospheric environment	In control cabinet, no corrosive gas, inflammable gas, oil mist or dust etc
vibration	less than 0.5G (4.9m/s <sup>2</sup> ) 10 Hz -60Hz (not run continuously)
Protection level	Ip54

When several drives installed in the control cabinet, please keep enough space for sufficient heat dissipation; please add an additional cooling fan to keep the drive ambient temperature below 55 °C .

Please install the drive by vertical way, face forward, top up for heat dissipation.

Avoid any drilling cuttings or other things falling in the drive during assembly.




Please use M4 screws when installing.

If there is vibration source (punch) nearby and can not avoid it, please use vibration absorber or add anti-vibration rubber gasket.

If there is a large magnetic switch, welding machine etc noise interference sources nearby, the drive is easily interfered by outside and make wrong action, therefore, a noise filter must be added; but the noise filter will increase leak current, so, an insulating transformer must be installed at the input end of the drive.


### 1.3.2 Servo installation direction and interval

Below chart shows a drive and multiple drives installation interval, the interval should be larger enough for a good heat dissipation conditions.



# Chapter 2 Servo drive and motor wiring


## 2.1 Servo drive power supply and peripheral devices wiring



**SDD04NK7 servo drive peripheral devices wiring**




## Chapter 2 Servo drive and motor wiring



### SDD20NK9 servo drive peripheral devices wiring


Chapter 2 Servo drive and motor wiring

**2.2 Position control mode wiring diagram 1**




**position control mode wiring diagram**

## 2.2.2 Position control mode wiring diagram 2




## 2.3 internal position control mode wiring diagram (simple PLC function)



**Internal position control model wiring diagram**

Chapter 2 Servo drive and motor wiring



**locking type brake motor wiring diagram**

**2.5 Terminal electrical connection**

**2.5.1 1、 Definition of the power terminal (SDD04NK7 series)**

	Terminal marking	signal definition	function
	L	power supply	power input terminal ~220V 50Hz note: do not connect with motor output terminal U, V, W.
	N		
	P	external connect	Built-in braking resistor: P and D short circuit connection.
	D	brake resistor select terminal	With external braking resistor: P and D open. The external resistance connection between P and C.
	C		
	PE	System grounding	1、 grounding terminal resistance <math>< 100\Omega</math>; 2、 Servo motor output and power input with one public point grounding.
	W	Servo motor output	Servo motor output terminals must connect with motor terminals W,V,U
	V		
	U		

## 2、 Power terminal definition

	Terminal marking	signal definition	function
	L1	Power supply single-phase or three phase	power input terminal $\sim 220V$ 50Hz, single phase connect L1 L2 note: do not connect with motor output terminal U, V, W.
	L2		
	L3		
	PE	System grounding	grounding terminal resistance $< 100\Omega$ ; Servo motor output and power input with one public point grounding
	U	Servo motor output	Servo motor output terminals must connect with motor terminals W,V,U
	V		
	W		
	P	external connect brake resistor select terminal	Built-in braking resistor::P and D short circuit connection.
	D		With external braking resistor:P and D open.The external resistance connection
	C		between P and C.

### 2.5.2 Power line terminals wiring

- L1, L2, L3, PE, U, V, W terminal, transversal area  $\geq 1.5\text{mm}^2$  (AWG14-16). L, N terminal, transversal area  $\geq 1.0\text{mm}^2$  (AWG16-18)。
- Grounding: the grounding wire should be as thick as possible, drive and servo motor grounding at PE terminal, grounding resistance  $< 100\Omega$ 。
- Suggest providing power supply by three-phase isolating transformer to reduce the possibility of electric shock hurts.
- Suggest providing power supply by the noise filter to improve the anti-interference ability.
- Please install non fuse type(NFB) circuit breakers, so that the external power supply can be cut off promptly when the drive with failure.



## 2.4.4 Signal terminal definition

SDE servo drive unit interface terminal configuration as follows. CN1 signal control terminal is DB25 connector, the socket is pin type, plug is hole type; The CN2 feedback terminal is a DBM15 connector, the socket is a three-row 15-pin hole type, and the plug is a three-row 15-pin type.

### 1) Control terminal CN1

Terminal No	signal name	mark	I/O	System default function
CN1-8	Control Power supply positive	COM+	power supply	Power supply positive pole of input terminal Photoelectric coupler used for drive the input terminals DC12 ~ 24V, electric current $\geq 100\text{mA}$
CN1-21	Input port 1	IN0(SON)	input	System default : input terminals of Servo-enabled: SON ON: allow the drive to work. SON OFF: drive off, stop working, the motor in free state.
CN1-9	Input port 2	IN1 (ARST)	input	System default: servo alarm clear ON: servo alarm output normally OFF : remove the system alarm
CN1-20	Input port 3	IN2(CCW)	input	System default: Forward drive prohibition
CN1-17	Input port 4	IN3(CW)	input	System default: Reverse drive prohibition
CN1-22	Input port 5	IN4(CLE)	input	System default : position deviation counter reset CLE ON: position control, position deviation counter reset
CN1-10	Input port 6	IN5(INH)	input	System default : position command pulse prohibit input terminals INH ON: command pulse input prohibited CX INH OFF: Command pulse input effective
CN1-4	Input port 7	IN6 (GEARI)	input	System default: electronic gear ratio choose terminal ( default as OFF ) ON: choose PN31 parameter as present position control gear ratio OFF : choose PN9 parameter as present position control gear ratio
CN1-1	Input port 1	OUT1	output	System defaults: location arrival: The position speed

		(COIN)		reaches the signal output terminal, and the output turns ON when the servo position approaches the target position (Pn12 parameter setting value).
--	--	--------	--	--

Terminal No	signal name	mark	I/O	System default function
CN1-14	Output port 2	OUT2 (HOLD)	output	System default: brake output Open-drain output, normal working, optocoupler breakover. Output ON No enable, drive prohibited. When alarm, optocoupler cut-off; output OFF
CN1-15	Output port 3	OUT3 (ALM)	output	System default: servo alarm output ALM ON: servo drive without alarm, servo alarm output ON. ALM OFF: servo drive alarm, servo alarm output OFF.
CN1-3/16	common terminal of the output	DG	common terminal	Grounding common terminal of the control signal output terminal(except CZ)
CN1-2	encoder Z phase output	CZ+	output	the encoder Z phase output terminals: photoelectric code of the servo motor Z phase pulse output CZ ON: Z phase signal appear, optocoupler collector open circuit output
CN1-5	encoder Z phase output	CZ-	output	
CN1-18	Command pulse	PULS+	input	external Command pulse input terminals Note 1: the parameter Pn8 set pulse input model; 0. Command pulse+symbol mode; 1. CCW/CW Command pulse mode; 2. A/B orthogonal Command pulse mode
CN1-6		PULS-		
CN1-19	command direction	SIGN+	input	
CN1-7		SIGN-		
CN1-23	Output encoder signal A	PEA	output	Each round of the motor with pulse output The output pulse is mainly used to return to the upper machine. To achieve closed loop control, the frequency of the output signal can be set by PN41
CN1-11		PEAL	output	
CN1-24	Output encoder signal B	PEB	output	
CN1-12		PEBL	output	
CN1-25	Output encoder	PEZ	output	Each motor round output a signal, the width of

CN1-13	signal Z	PEZL	output	the signal related to the speed of the motor
CN1-PE	Shield ground	PE		

## 2) The feedback signal terminal CN2

terminal No	signal name	terminal mark	I/O	function
CN2-11	Encoder battery positive	VB+		Encoder battery positive
CN2-2	Serial encoder signal	SD+	Two way	Serial data
CN2-12	Encoder battery negative	VB-		Encoder battery negative
CN2-7	Serial encoder signal	SD-	Two way	Serial data
CN2-14	Digitally ground	GND		Digitally ground
CN2-15	+5V power supply	VCC		power supply
CN2-13	Shielding ground	FG		

## 3) Serial communication terminal (SDE\*\*NK\*\*) CN3/CN5

terminal No.	signal name	mark	Model	function
6	Digitally ground	GND	SDE** NK**	Digitally ground
5	power supply	VCC		power supply
3	RS485 communication signal	485D+		RS485 communication signal
1	RS485 communication signal	485D-		RS485 communication signal

## 4) Serial communication terminal (SDE\*\*NK\*\*A) CN3/CN5

terminal No.	signal name	mark	Model	function
3	RS485 communication signal	485D-	SDE** NK**A	RS485 communication signal
4	RS485 communication signal	485D+		RS485 communication signal

Through two terminals CN3 CN5 can be interconnected into multiple networking communications.

Terminal interface as shown below (SDE\*\*NK\*\*and SDE\*\*NK\*\*A ports):

Terminal interface as shown below (SDD\*\*NK\*\* and SDD\*\*NK\*\*D ports):



**SDD\*\*NK\*\***



**SDD\*\*NK\*\*D**


### 2.5.4 signal terminals wiring

- Cable selection: use shield cable (It is better to choose twisted shielded cable), wire core cross-sectional area  $\geq 0.12\text{mm}^2$  (AWG24-26), shield must connect with FG terminals.
- cable length: cable length as short as possible, CN1 control cable should be less than 3meters, signal feedback CN2 cable should be less than 20meters.
- Wiring: away from power cabling to prevent interference entering. Please install surge absorber component in the relevant circuit inductor components (coil); direct current coil anti-parallel free-wheeling diode, AC coil in parallel and RC absorb return circuit.

## 2.6 The principle diagram of the signal interface


### 2.6.1 digital input interface circuit

Digital input interface circuit could be controlled by relay or open collector transistor circuit. User provide power, DC12 ~ 24V, current  $\geq 100\text{mA}$ ; note: if the current polarity reversed, the drive does not work. Input signal IN0-IN6 all can refer to this connection mode.



## Chapter 2 Servo drive and motor wiring

When input signal connect with OV, signal is ON input and effective. It can be judged by display menu UN-17, when input ON, the corresponding nixie tube will be light. Input OFF, the corresponding nixie tube will die out. Use this display content properly, convenient for servo input signal debugging and maintenance.




Input terminal display

(The stroke is lit to indicate ON, and to be off to indicate OFF)


### 2.6.2 Servo motor photoelectric encoder input interface

In the differential output mode, use AM26LS32、MC3487 or similar line drive RS422 as a receiver.



### 2.6.3 The pulse signal input interface circuit


In order to transmit pulse data correctly, suggest to use differential drive way; in differential drive mode, use AM26LS31、MC3487 or similar line driver RS422 as follow diagram




Using single-ended drive mode will lower the operating frequency.

## Chapter 2 Servo drive and motor wiring

A: Input circuit according to the pulse quantity. drive current 10~25mA Limit external power maximum voltage as 24V, determine the value of resistance R. experience data:VCC=24V, R=1.3~2k; VCC=12V, R=510~820Ω。External power supply provided by user, please note that if the power polarity reversed, the servo drive unit will be damaged. Details as follow diagram.




B: Don't concatenated resistance, with the internal resistance of the drive function implementation. The wiring method as diagram below.







Chapter 2 Servo drive and motor wiring

**2.6.4 driver speed output interface**



**2.6.5 The digital output interface circuit**

Please pay attention to the power polarity when using external power, reversed polarity will damage the drive. Digital output is open collector mode, limit external voltage maximum as 24V, maximum current is 10mA. In terms of load, when using relay etc inductive load, a diode need be added to parallel with inductive load, if the polarity of the diode is reversed, the drive will be damaged. The status of the output signal can be observed by IIN-18



Output terminal display

Light display ON, go out display OFF

## Chapter 3 operation and display

### 3.1 Keyboard operation







- Servo panel with 6 LED nixie tube display and 4 buttons to display various status, parameter setting . Key functions as follows:

- ▲: number, value increase, or forward.
- ▼: number, value decrease, or back.
- ◀: return to upper menu or cancel the operation.
- ↵: enter the next layer operation menu or input confirmation.


Note: ▲、▼ keep press down, repeat operation, the longer the holding time, the faster the repetition rate.

\*\*\* 6 section LED digital tube display all kinds of status and data of the system, all digital tube or the decimal point of the rightmost digital tube blink, it means alarm.




\*\*\* According to multiple-layer menu to operate, the first layer is main menu, including 8 kinds operation mode, the second layer is the function menu of all operation modes. The below diagram shows the main menu operation:



















Display status	meaning
	Status surveillance
	parameter
	Parameter operation
	Internal speed run
	Jog operation
	Encoder adjustment

Chapter 3 operation and display




























	Open loop run
---	---------------

**3.2 Monitoring method**

Choose “Un-” in the first layer, press  entering monitoring mode; there are 22 display status, the user use ,  to choose the display mode.

















Display status	Display code	Display meaning	Example
		Motor speed	Current motor speed is 500 turn
		present position low 5	
		present position high 5	
		Command pulse low 5	
		Command pulse high5	
		Position deviation low 5	
		Position deviation high 5	
		Motor torque	
		Motor current	


Chapter 3 operation and display

		present linear speed	
		Control mode	
		pulse frequency	
		Speed command	
		Torque command	
		Rotor absolute position	
		Empty	
		Input signal status	
		Output signal status	
		Encoder signal status	
		Running status	
		Alarm code	
		Reserve	
		Display analog AD value	

## Chapter 3 operation and display

### 3.3 Parameter setting

Choose “PN-” in the first layer, and press key  to enter parameter setting mode. Use 、 to choose parameter, press key , display the value of the parameter, use 、 to modify parameter values. press  or  once, parameter increase or decrease one, press and keep  or , the parameter can be increase or decrease continuously. When the parameter value is modified, the rightmost LED digital tube lit up, press  to make sure the modified value effective, the LED digital tube decimal point of the right side go out, the modified value will be reflected in the control immediately, then press  or  keep on modify parameter, after modified press  back to the parameter selection status. If you are not satisfied with the value you are modifying, do not press , can press  to cancel, restore original parameter value, and back to the parameter selection status.



### 3.4 Parameter management


Parameter management mainly deals with the operation between memory and EEPROM, choose "Sn-" in the first layer, and press entering parameter management mode. First, choose the operation mode, there are 5 modes, use , to choose. Take "parameter write in" for example, choose "Sn-Set", press



Chapter 3 operation and display

← and keep more than 2 seconds, if the write success, display “DONE”, if fail, display “ERR”. Press ← again back to the operation mode selection status.

**Sn – SEt** parameter write in, it means to write the memory parameter to the parameter area of EEPROM. When the users changed the parameters, only the memory parameter values changed, next power supply will be restored to the original value. If you want to change the parameter values permanently, need to perform write in operation, write the memory parameter into parameter area of EEPROM, next power supply will use the modified parameters.




- **Sn – rd** parameter read, it means read EEPROM data in parameter area into the memory. The process will perform automatically when power on, at the beginning, the memory parameter and the EEPROM parameter is the

Chapter 3 operation and display






same. But when the user modified the parameter, the memory parameter value changed too. When the user is not satisfied with the modified parameter or the parameter is messy, perform the parameter read operation, the data in the ENPROM parameter area will read into the memory again and restore to the original parameters when power on at the first time.


- **Sn—SS backup parameters**
- **Sn—rS Restore backup area parameters to current memory**
- **Sn—dEF** restore default value, it means to read all the parameter default value(factory defaults) into the memory, and write in the EEPROM parameter area, next power on will use the default parameter. When the user messed the parameter and can not work properly, use this operation can restore all parameters to factory default. As different drive mode with different parameter default values, when using restore default parameters, firstly have to ensure the motor ID (parameter PN1) is correct.



Chapter 3 operation and display


**3.5 F1 operation mode (panel test-run function)**



Choose “F1-” in the first layer, press  entering speed trial operation mode. Speed trial prompt is “S”, value unit is r/min. Speed command provided by keys, use  ,  can change speed command. The motor operated at the given speed.  Control the speed positive increasing,  control the speed reducing (reverse increasing). When the speed value is positive, the motor rotated in the forward direction; when the speed value is negative, the motor rotated in the reverse direction. **Note: the speed mode is a continuous motion, please ensure the motion axes with enough run distance to avoid impact and limit.**




**Note: if without outside enable signal, please set PN95 parameter as 1. Or the motor won't work.**

**3.6 F2 run mode(JOG run test function)**

Choose “F2-” in the first layer, press  entering jog operation mode. JOG run prompt is “J”, value unit is r/min , speed command provided by keys. Enter F2

operation, press  key and keep, motor run at jog speed, release the button, motor stop running, retain zero speed; press  and keep, the motor inverted running at jog speed, release the key, the motor stop running, retain zero speed, jog speed set by parameter PN22.



**Note:** if without outside enable signal, please set PN95 parameter as 1. Or the motor won't work.

### 3.7 Other

F4 is the photoelectric encoder zero set function, for motor manufactures use. The user can not use it.

F5 function reserve.

## Chapter 4 parameter

SDD series servo with total 127 parameters can be adjusted, adjust the user parameters can meet most requirements of the user. The motor mating parameters can not be modified randomly, or there will be unpredictable results appear. Pn5-Pn16 are position control parameters, Pn17-42 are speed control parameters, Pn43-Pn50 are current control parameters, Pn51-Pn59 are I/O control parameters. Pn60-Pn96 are motor mating parameters. Pn97- Pn127 are internal control parameters and communication control parameters.

No.	Name	No.	Name
0	Parameter password	1	Motor ID
2	Software version	3	initial display status
4	control mode	5	position proportion gain
6	position feed forward	7	position feed forward low pass filter cut-off frequency
8	Position command pulse input form	9	Position command pulse fractional frequency numerator
10	Position command pulse fractional frequency denominator	11	Position command / code wheel feedback direction selection
12	Positioning completion range	13	Position out of tolerance detection range
14	Position out of tolerance error invalid	15	Position command smoothing filter
16	drive ban input invalid	17	speed proportion gain
18	speed integral time constant	19	speed detection low pass filter
20	Rated speed	21	Arrive speed
22	Jog speed	23	Enable delayed
24	Back to zero absolute positioning pulse number	25	Absolute positioning circle when oriented
26	Back to zero speed	27	Back to zero accredited range

28	Return to zero single/ Multiple circle selection	29	Acceleration time constant
30	Deceleration time constant	31	Position command pulse fractional frequency numerator 1
32	Speed feedforward filter coefficient	33	Speed 1
34	Speed 2	35	Speed 3
36	Speed 4	37	Speed 5
38	Speed 6	39	Speed 7
40	Speed 8	41	Encoder output signal frequency
42	Reserved	43	Current loop proportional gain
44	Current loop integral time constant	45	Internal torque 1
46	Internal torque 2	47	Internal torque 3
48	Internal torque 4	49	Torque setting
50	Torque command filter	51	Input port low 4 force effective
52	Input port high 4 force effective	53	input port low 4 reverse
54	input port high 4 reverse	55	output port reverse
56	IO port sampling time	57	The second position proportion gain
58	Historical alarm record	59	Production Date
60	Motor inertia ratio	61	Motor rated torque
62	motor rated speed	63	Motor maximum speed
64	motor rated current	65	Maximum overload capacity allowed by the system
66	Current integral separation point	67	Current proportional gain rate of change
68	Current command low pass filter	69	Speed integral separation point
70	output port 1 function selection	71	output port 2 function selection
72	output port 3 function selection	73	Current sampling filtering times
74	blank	75	Overload torque detection point
76	Overload point torque	77	Maximum overload time of the overload point

78	Maximum braking time	79	Speed amplifier saturation detection time
80	Speed feedforward coefficient	81	Blank
82	Input pulse filter frequency	83	Key response time
84	Current detection coefficient	85	Position difference clearing method
86	Encoder line number	87	Encoder battery detection
88	Current when encoding disk is zero	89	Motor thermal overload
90	Motor thermal overload torque	91	Motor thermal overload time
92	Motor pole pairs	93	Open loop operating current
94	Open loop speed	95	Forced enable
96	Module current limit	97	Internal position 0 laps
98	Internal position 0 pulse number	99	Speed at internal position 0 positioning
100	Internal position 1 turns	101	Internal position 1 pulse number
102	Speed at internal position 1 positioning	103	Internal position 2 turns
104	Internal position 2 pulse number	105	Speed at internal position 2 positioning
106	Internal position 3 turns	107	Internal position 3 pulse number
108	Speed at internal position 3 positioning	109	Acceleration and deceleration of the internal position
110	Input port 0 definition	111	Input port 1 definition
112	Input port 2 definition	113	Input port 3 definition
114	Input port 4 definition	115	Input port 5 definition
116	Input port 6 definition	117	RS485 communication address
118	RS485 communication rate	119	RS485 communication agreement
120	Position/speed integral saturation fault detection	121	Input port is controlled selection
122	Notch center point frequency	123	Notch width
124	Notch depth	125	Torque mode speed limit
126	High speed torque factor	127	Software version of the FPGA

#### 4.1 All parameters function and significance detail list

No.	name	function	parameter range
0	parameter password	① password with different level, corresponding to user parameters, system parameters ② To modify the motor ID(Pn1) , must set this item to 0, user parameter password is 168. Please consult the manufacture for system parameters.	0~300
1	Motor ID	For supporting motor model. Each motor with a unique ID number, Set password Pn0 to be 0 firstly, then modify this parameter. After the setting is completed, the SN-DEF needs to be executed to be valid. Please operate this parameter with caution.	0~100
2	software ID	Reserved by the manufacturer	
3	initial display status	Choose the display status when the drive power on 0: display motor rotation speed; 1: display current position low 5; 2: display current position high 5 8: display motor current; 11:display position command pulse frequency; 12:display speed command; 13:display torque command; 14:Display the rotor absolute position	0~20
4	control mode	The drive control mode can be set by this parameter: 0: position control mode; 1: internal position/speed/torque control mode 2: internal speed control mode; 3: jog control mode. The internal position/speed/torque is determined by the I/O port.	0~5



5	position proportion gain	Set the proportion gain of the location loop regulator. The greater the setting value, the higher the gain, and the greater the stiffness, under the same frequency command pulse condition, the location hysteresis will be less. But if the value is too big may cause oscillation or overshoot.	1~1000
6	position feed forward	When the feed forward gain of the location loop increase, the high-speed response characteristics of the control system will be enhanced, but it make the system location loop unstable and easy to vibrate. Unless very high response characteristics needed, the location loop feedforward gain usually set to 0.	0~100
7	position feed forward low-pass filter cutoff frequency	set position loop feedforward low-pass filter cutoff frequency, the high the cutoff frequency, the better the position tracking, but easy to vibrate.	1~1200
8	position command pulse input form	Set the position command pulse input form 0: pulse+ sign; 1: CCW pulse/CW pulse; CCW is observed from the axial of servo motor, counter clockwise rotate, it defined as forward direction. CW is observed from the servo motor axial, clockwise rotate, it defined as reverse direction. 2: A/B orthogonal signal	0~2
9	position command pulse frequency division numerator	electronic gear ratio numerator	1~32767

10	position command pulse frequency denominator	electronic gear ratio denominator	1~32767
11	Position command / encoder feedback direction selection	0: The position command is normal, and the encoder feedback is normal; 1: The position command is reversed and the encoder feedback is normal; 2: The position command is normal, and the encoder feedback is reversed; 3: The position instruction is i reversed, and the encoder feedback is i reversed.	0~3
12	Positioning finished range	set the positioning finish pulse range under the position control; This parameter provide basis whether drive unit judgment finished positioning under the position control mode.	0~30000
13	Position tolerance detection range	set position tolerance alarm detection range; Under the position control mode, when the count value in the position deviation counters over this parameter, the servo drive unit will give position error alarm.	0~30000
14	position error invalid	0: position error alarm detection valid; 1: position error alarm detection invalid, stop detecting location error.	0~1
15	position command smoothing filter	smooth filtering command pulse, with exponential form acceleration and deceleration, numerical value means time constant; The filter will not lose input pulse, but there will be command delay phenomenon; When set to 0, the filter doesn't work.	0ms~2000 0×0.1ms
16	drive ban input invalid	0: CCW、CW input ban valid; 1: cancel CCW、CW input ban.	0~1

17	speed proportion gain	Set the speed loop regulator proportion gain. 1. The greater the setting value, the higher the gain, and the greater stiffness. 2. The greater the load inertia, the greater the setting value.	5Hz ~2000Hz
18	speed integral time constant	Set speed loop regulator integral time constant; 1.The smaller the set value, the faster integral speed and the greater stiffness. 2.The greater load inertia, the greater of set value. At the frequent start-stop small power occasion, the set value is small to prevent overshoot.	1ms ~1000ms
19	speed detection low pass filter	set speed test low pass filter characteristic; 1. The smaller value, the low cutoff frequency, the smaller of the motor noise. If the load inertia is large, could reduce the setting value. If the value is too small may cause to low response and vibration. 2. The larger the value, the higher the cutoff frequency, the speed response faster. If high speed response needed, could increase the setting value.	1%~500%
20	rated speed	rated speed of the motor	0~ 4000
21	reach speed	Set the speed value when input signal reach effective	0~3000
22	jog speed	Set jog speed.	-3000~300 0r/min
23	Enable delay		0-1000ms
24	Orientation absolute positioning pulse count	Precise position when external triggering orientation control Actual operation position is set value *2	0-65536
25	Absolute positioning circle when oriented	The precise position when the external orientation control is triggered.	0-3000
26	Orientation speed	The speed when external triggering orientation control, by setting plus or minus speed to decide rotation direction when positioning.	0~3000 r/min

27	Orientation complete range	Identified range when external triggering orientation control	0-10000
28	Return to zero single/ Multiple circle selection	Choose whether to align within a single circle or directional control within multiple turns. PN25 is meaningless when oriented in a single circle. 0: multi-turn orientation; 1: Single circle orientation.	0-1
29	Acceleration time constant	Set value means the motor acceleration time from 0r/min~1000r/min. Acceleration and deceleration are linear. Only used for speed control mode, it is invalid for position control mode;	0ms ~1000ms
30	deceleration time constant	Set value means the motor deceleration time from 0r/min~1000r/min. Acceleration and deceleration are linear. Only used for speed control mode, it is invalid for position control mode;	0ms ~1000ms
31	Position command pulse frequency second numerator	Position control the second gear ratio numerator	1~65536
32	Speed feedforward filter coefficient	Set the low-pass filter cutoff frequency of the speed loop feedforward. The higher the cutoff frequency, the better the position tracking, but it is easy to oscillate.	0~1000
33	speed 1	Internal speed control mode: by external I/O point status to control the speed. For example: OFF OFF OFF : Pn33 OFF OFF ON : Pn34 OFF ON OFF : Pn35 OFF ON ON : Pn36 ON OFF OFF : Pn37 ON OFF ON : Pn38	-3000~300 0r/min
34	speed 2		-3000~300 0r/min
35	speed 3		-3000~300 0r/min
36	speed 4		-3000~300 0r/min

37	speed 5	ON ON OFF : Pn39 ON ON ON : Pn40	-3000~300 0r/min
38	speed 6		-3000~300 0r/min
39	speed 7		-3000~300 0r/min
40	speed 8		-3000~300 0r/min
41	Encoder output signal frequency	The number of output pulses per revolution of the motor is set.	1~65536
42	Reserved		
43	Current loop proportional gain	1. The higher the set value, the greater the gain, the current tracking error is smaller. But too much gain will produce vibration or noise, 2.it related with the servo motor, 3. Independent of load	1~500
44	current loop integral time constant	1.The smaller the set value, the faster the integral speed, and the current tracking error is smaller. But too small integral will produce vibration or noise.2. It related with servo motor, 3. Independent of load. 4.Try to set larger value under the condition of the system without vibration.	1~10000
45	Internal torque 1	内 Internal torque control mode: the size of the torque is controlled by the status of the external I/O point. For example: T0 T1 : OFF OFF: Pn45 ON OFF: Pn46 OFF ON : Pn47 ON ON : Pn48	0%~300%
46	Internal torque 2		-300%~0%
47	Internal torque 3		0%~300%
48	Internal torque 4		-300%~0%
49	torque set	internal speed, jog speed torque	0~300%

50	torque command filter	<p>1. Setting the torque command filter characteristics can restrain the vibration which produced by torque (the motor give out sharp vibration noise).</p> <p>2. The smaller of the value, the lower of the cutoff frequency, the smaller noise produced by motor. If the load inertia is very big, can reduce the set value properly. If the value is too small, may result in slow response and may cause instability.</p>	1%~500%
51	Input low 4 enforce effective	The lower four bits of the input signal are forced ON.	0-15
52	Input high 4 enforce effective	Input signal high 4 enforce ON	0-7
53	input low 4 reverse	input signal low 4 reverse, used to match the electrical level of the input signal contact spot	0-15
54	input high 4 reverse	input signal high 4 reverse, used to match the electrical level of the input signal contact spot	0-7
55	output port reverse	Output signal reverse, used to match the electrical level of the output signal	0-15
56	IO port sampling time	IO port sampling time	1~1000*0.1 ms
57	The second position proportion gain	The function is same with PN5, which parameter used as position proportion gain in system, is determined by external I/O, in default situation, with PN5 as system internal position proportion gain.	1-65536
58	Historical alarm record	Original alarm record	0~50
59	Production Date	Indicates the drive production date.	
60	Motor inertia ratio	Set the motor inertia ratio.	1~32767
61	motor rated torque	set motor rated torque	1~1000

62	motor rated speed	Set motor rated speed.	0~4000 r/min
63	Motor maximum speed	Set motor maximum speed	0~5000 r/min
64	motor rated current	Set motor rated current. Set value is valid.	1~500× 0.1A
65	Maximum overload capacity allowed by the system	Set system allowed maximum overload multiple	0~300%
66	Current integral separation point	Current error over the set value, the current loop from PI change to P, value is the percentage of rated current	0~500%
67	Current proportional gain rate of change	Set the current proportional gain change rate. When large current deviation is required, increase the current gain to increase the current response speed, usually 100%.	100~400%
68	current command low pass filter	Set current command low pass filter cutoff frequency. Used to limit the current command frequency band, avoid the current shock and vibration, and make the current response stably.	1~1500HZ
69	Speed integral separation point	When speed error over the set value, the speed change from PI to P	0~3000 r/min

70	Output port 1 function selection	<p>Set output port 1 function:</p> <p>0: break output function</p> <p>1: servo alarm output</p> <p>2: position reach</p> <p>3: speed reach</p> <p>4: servo ready</p> <p>5: back to zero complete</p>	0-5
71	Output port2 function selection	Set Output 2 function: refer to Pn70	0-5
72	Output port3 function selection	Set Output 3 function: refer to Pn70	0-5
73	Current sampling filtering times	In order to meet the requirements of different occasions, different parameter settings are adopted to meet the requirements of speed stability and fast response. The fewer the number of times, the slower the system response, but the smoother the vibration, the smaller the vibration.	1~25
75	Overload torque detect point	<p>Set the start torque value of the overload protection, rated percentage.</p> <p>When the present torque over this value, the system internal overload counter work, counter exceeds, system output overload alarm.</p>	0-300%
76	Overload feature point torque	Set overload point torque, This parameter and Pn77 make up the overload characteristic of the motor together. Set by the motor overload characteristic parameters. Note Pn76» Pn75	0-300%
77	Maximum overload time of the overload point	refer to Pn76	0-3000× 10 ms



78	Reserved	Reserved	
79	Speed amplifier saturation time	When the continuous saturation time of the system's internal speed regulator exceeds this value, a speed saturation alarm is generated. Used to prevent mechanical jamming or other reasons caused the continuous current larger.	0-3000 × 10 ms
80	Speed feedforward coefficient	The feedforward gain of the speed loop increases, and the high-speed response characteristic of the control system increases, but the position loop of the system is unstable and is prone to oscillation. The feedforward coefficient is usually zero unless a high response characteristic is required.	0~5000
82	Input pulse filtering frequency	Set input pulse pass frequency, unit 1 means 1KHZ, set at 500, means the system maximum pass frequency is 500KHZ.	1-10000
83	Key period	The key response time	2~200
84	Current detection coefficient	Current detection coefficient, system setting, cannot be changed at will;	1~32767
85	Position difference removal method	0: no enable status, position deviation command pulse accumulation reset 1: no enable status, position deviation command pulse accumulation is not reset, count continuously.	0-1
86	Encoder line	Encoder line 17BIT 131072。	17
87	encoder battery detection	0: The encoder battery is not detected. 1: Detect the encoder battery and the alarm is valid;	0-1
88	Encoder current when reset	Set current value when the encoder reset, the percentage cannot too big to avoid motor overheating	0-300%
89	Motor thermal overload torque detect point	Thermal overload use I*I*T calculate method	10-300%

90	Motor thermal overload torque	Set this parameter bigger than Pn89	10-300%
91	Motor thermal overload time	Set thermal overload maximum time	0-1000S
92	motor pole pairs	Set servo motor pole pairs, different manufacture and different model motor may with different pole pairs, cannot change this parameter randomly	1~36
93	Open loop operating current	Set the maximum current for open loop operation.	1~100× 0.1A
94	Open loop speed	Set the speed of the open loop operation.	0~3000 r/min
95	Force enable	0: servo enable is controlled by external I/O 1: automatic servo enable when forced power on, do not need to connect external signal	0~1
96	Maximum allowable current of the system 1	Reserved.	0-800
97	Internal position 0 turn	Set internal position 0 precise position When the internal position control: target position determine by these 2 parameters, position 0= Pn97*131072+ Pn98*2	0~4000
98	Internal position 0 pulse	For example: Pn97=2 Pn98=1000 Indicates internal position movement =2*131072+2000=264144unit	1~65536
99	Speed at internal position 0 positioning	The speed of positioning to internal position 0	0~3000 r/min
100	Internal position 1 turn	Set internal position 1 precise position	0~4000
101	Internal position 1 pulse	Refer to Pn97 Pn98	1~65536


102	Speed at internal position 1 positioning	The speed of positioning to internal position 1	0~3000 r/min
103	Internal position 2 turn	Set internal position 2 precise position Refer to Pn97 Pn98	0~4000
104	Internal position 2 pulse		1~65536
105	Speed at internal position 2 positioning	The speed of positioning to internal position 2	0~3000 r/min
106	Internal position 3 turn	Set internal position 3 precise position Refer to Pn97 Pn98	0~4000
107	Internal position 3 pulse		1~65536
108	Speed at internal position 3 positioning	The speed of positioning to internal position 3	0~3000 r/min
109	Acceleration of the internal position	Acceleration and deceleration time when internal positioning, the greater the value, the faster the acceleration.	0~2000
110	Input port 0 definition	Servo enable function, this input port cannot define other functions	1
111	Input port 1 definition	Used to define the function of the input port, for the convenience of customers The set value and functions as follows: 0: no definition, no function	0-21

		2: alarm clear 3: input pulse prohibited 4: position deviation counter reset 5: speed command input 0 6: speed command input 1 7: speed command input 2 8: blank 9: position gain switch 10: position gear ratio numerator switch 11: blank 12: torque command input 0 13: torque command input 1 14: positive drive prohibited 15: reverse drive prohibited 16: internal position command 0 17: internal position command 1 18: internal position running start 19: internal control method option 0 20: internal control method option 1 21: directional control functions	
112	Input port 2 definition	Refer to Pn111	0-21
113	Input port 3 definition	Refer to Pn111	0-21
114	Input port 4 definition	Refer to Pn111	0-21
115	Input port 5 definition	Refer to Pn111	0-21
116	Input port 6 definition	Refer to Pn111	0-21
117	Communicate address	More than one drive communicate, set the station number	0-127

118	Communication rate	Communication rate: 0: 4800                      1: 9600 2: 19200                    3: 38400 4: 57600                    5: 115200	0-5
119	Transport protocol	Transport protocol, use RTU mode 0: 8 0 1 (MODBUS, RTU); 1: 8 E 1 (MODBUS, RTU); 2: 8 N 2 (MODBUS, RTU) Note: 8 means 8 bits data, E means 1 even O means 1 odd    1 means 1 end bit	0-1
120	position/speed integral saturation fault detect	0: detect integral saturation fault 1: do not detect integral saturation fault	0-1
121	position/speed integral saturation fault detect	0: detect integral saturation fault 1: do not detect integral saturation fault 2: The enable signal is controlled by the port and other signal communication control.	0-2
122	Notch center point frequency	Set the notch parameter to suppress mechanical resonance.	0-10000
123	Notch width	When the trap depth is set to 100, the notch does not work	0-10000
124	Notch depth		0-100
125	The speed limit of torque mode	Torque control mode to limit the speed	0-4000
126	High speed torque coefficient	Ascension of coefficient of high speed torque	0-500
127	FPGA version display	Display the companion FPGA version.	0-1000

44

#### 4.2 parameter adjust diagram model



### 4.3 Description of Servo key parameters

As the default motor mating parameters has been optimized, therefore, the parameters (except electronic gear) do not need to adjust in most applications and can be used directly. But the actual mechanic is complex. If abnormality appear or needs high response when adjusting, then need to adjust the parameters to meet requirement. The adjustment principle is first current loop, second speed loop, last position loop.

The current loops do not need to adjust except for individual situation. The too fast speed response results in current shock and AL11 alarm. It can adjust PN64 to solve.

**Speed loop:** If high speed response needed, can increase PN17 or decrease PN18. However, the PN17 setting too large will cause vibrate. In the occasion of too big load inertia, if the load motor park unstably when decelerating and wag from side to side, need to increase PN18 to solve.

**Position loop:** If high location response needed, can increase PN5. Some occasions can increase PN6 to meet requirement. But PN5 PN6 is too large will cause vibrate. The setting precondition is to adjust PN5 prior, only in the short distance and high response occasion can use PN6.

**electronic gear ratio: 1 )** if calculate from rotate speed angle, the below formula can be used

$$f \times (PN9/PN10) = 131072$$

in which f denotes the upper computer pulse, unit is KHZ/circle

If knows the pulse number from the upper computer and make the motor or load turn a circle, the gear ratio set value can be calculated with the above formula.

Chapter 4 parameter

2) calculate according to the position accuracy directly

$$(\text{lead/pulse equivalent}) \times (\text{PN9/PN10}) = 10000$$

For example: screw lead is 5mm, motor and screw lead connected directly, the motor rotates a circle, the load move 5mm. If the accuracy need 0.001mm, there are 5000 pulse needed for motor rotating a circle; that is: PN9=10, PN10=5

**Pulse input form:** support pulse with direction and double pulse (positive and negative pulse), set PN8

#### 4.4 parameter adjusting steps in actual application

In the process of adjusting or application, if there is vibration, noise or cannot reach the control accuracy, can adjust system parameters and meet the control requirement as the following methods.

When the motor is in static locking state, if there is vibration or sharp noise, please decrease parameter Pn43; set this parameter as large as possible under the condition without vibration. The larger the parameter, the better the current tracking effect and the faster the motor response; but too large parameter results in vibration or noise.

(1) : speed control mode parameters adjustment

1) [speed proportion gain] (parameter Pn17) set value, as large as possible under the condition without vibration. Generally, the larger of the load inertia, the larger of the set value.

2) [speed integral time constant] (parameter Pn18) set value, try to set as small as possible according to the given condition. If the set value is too small, the response speed will be increased, but easy to vibration. Try to set the value as small as possible under the condition of no vibration. If the value is too large, when the load changed, the speed will change bigger.

(2) : position control mode parameter adjustment

1) according to the above method to set proper [speed proportion gain] and [speed integral time constant].

## Chapter 4 parameter

2) [position feed forward gain] (parameter Pn6) set to 0%.

3) [position proportion gain] (parameter Pn5) set value, set as large as possible in the stable range. When the parameter is large, the position tracking will be good and hysteresis error is small, but easy to produce vibration when stop positioning. When the parameter is small, the system in stable state, but the position tracking become worse and hysteresis error become larger.

4) If position tracking requirement quite high, can increase Pn6 set value; but if it is too big, can lead to overshoot.



## Chapter 5 operation and adjustment

### 5.1 special attention during debugging:

- 1) (large/medium-power model suffix are K8) servo drive Connect the three phase AC 220V power to input terminal. three phase connect L1、L2、L3, single phase connect L2、L1.
- 2) (small power model suffix is K7) servo drive single phase connect L、N.
- 3) motor power line U, V, W, PE, the sequence cannot reverse.
- 4) Drive connection as above. The wrong connection may cause burning, motor does not run, alarm etc. please check the line connection correct or not.

#### 5.1.1 Power on sequence

- 1) When the power supply switch on, servo alarm signal output in 1S, after 1.5S signal output ready, after 10MS response to enable signal, less than 10MS motor excitation lock; waiting for running.

### 5. 2 Position control mode

- 1) Connect control circuit power and main circuit power, the display of the drive lighten. If there is alarm, please check the line connection.

- 2) Set below parameters:

parameter No.	parameter name	definition	Set value
Pn4	Control mode	0: position mode 1:internal position mode	0
Pn8	Position command pulse input mode	0: Single pulse 1: double pulse 2: A/B orthogonal pulse	0
Pn9	Gear ratio numerator		1
Pn10	Gear ratio denominator		1
Pn95	Servo enable	0: external enable 1: force enable	1

Chapter 5 operation and adjustment

3) Confirm there are no alarm and any abnormal situation, make enable servo (SON) ON, at this time, the motor motivated, in a state of zero velocity. If enable signal cannot connect wire, set Pn95 as 1 can make enable motor automatically.

4) Adjust the pulse frequency of the input signal; make the motor running according to command.



**5.3 speed trial run mode**

1) Connect control circuit power and main circuit power, the display of the drive lighten. If there is alarm, please check the line connection.

2) Set parameter as below:

parameter No.	parameter name	definition	Set value
Pn4	Control mode	0: position mode 1: internal position mode 2: trial run	2
Pn95	Servo enable	0: external enable 1: force enable	1

3) Confirm there are no alarm and any abnormal situation, make enable servo (SON) ON, at this time, the motor motivated, in a state of zero velocity. If enable signal cannot connect wire, set Pn95 as 1 can make enable motor automatically.

4) Through key operation enter F1 speed trial operation mode, speed trial operation prompt “S“, value unit is r/min, system in the speed trial mode, speed command provided by key, use   change speed command, the motor run based on the setting speed.

**5.4 Jog operation**



1) Connect control circuit power and main circuit power, the display of the drive lighten. If there is alarm, please check the line connection.

2) Set parameter as below:

Chapter 5 operation and adjustment

parameter No.	parameter name	definition	Set value
Pn4	Control mode	0: position mode 1: internal position mode 2: trial run 3: jog run	3
Pn95	Servo enable	0: external enable 1: force enable	1

3) Confirm there are no alarm and any abnormal situation, make enable servo (SON) ON, at this time, the motor motivated, in a state of zero velocity. If enable signal cannot connect wire, set Pn95 as 1 can make enable motor automatically.

4) Through key operation enter F2 speed trial operation mode, JOG run prompt “J”, value unit is r/min, system in the speed control mode, speed and direction determined by parameter Pn22, press  motor running according to the speed and direction which determined by Pn22, press  motor running opposite direction according to the given speed.

**5.5 Internal position/speed/torque control mode**

1) Connect control circuit power and main circuit power supply, the drive display light. If there is alarm, please check the line connection.

2) Set parameter as below:

parameter No.	parameter name	definition	Set value
Pn4	Control mode	0: position mode 1: internal position mode	1
Pn95	Servo enable	0: external enable 1: force enable	1
Pn111	IN1 definition	Define as position trigger	18
Pn112	IN2 definition	Define as orientation start	21
Pn113	IN3 definition	Define internal mode selection 0	19

Chapter 5 operation and adjustment

Pn114	IN4 definition	Define internal position 0	16
Pn115	IN5 definition	Define internal position 1	17
Pn116	IN6 definition	Define internal mode selection 1	20

3) Power off, re-up electricity, Confirm there are no alarm and any abnormal situation, make enable servo (SON) ON, at this time, the motor motivated, in a state of zero velocity. If enable signal cannot connect wire, set Pn95 as 1 can make enable motor automatically.

4) By switching the status of IN3 IN6 can switch under the mode position, speed and torque


Corresponding method as follows:

IN3. IN6 input signal status	Internal control mode
OFF OFF	position
ON OFF	speed
OFF ON	torque

5) By switching the status of IN4 IN5 can realize 4 point positioning movement, the speed of 4 point positioning movement and accurate position set by Pn97-Pn109.


IN4 IN5 input signal status	Internal control mode
OFF OFF	Position A
ON OFF	Position B
OFF ON	Position C
ON ON	Position D

## Chapter 5 operation and adjustment




### 5.5.1 Internal position application example

Use internal position control to realize the belowing 4 point movement mode.



## Chapter 5 operation and adjustment



### Internal position control applications Electrical wiring diagram

The framework consists of one of the simplest microcontrollers and this servo system. The one-chip computer is used to send three control signals to the servo to trigger the servo's internal position control mode and the precise positioning of the operation. This example can be omitted high-end computer such as: PLC motion controller. At the same time, interference during pulse transmission is eliminated. More accurate servo positioning. In the case of repeated positioning within four points, it has a very economical cost and excellent control performance.

Control detailed description: IN3 IN6 signal connect with OV signal, it means choose internal position control mode. IN0 signal connect with OV signal, it means choose servo automatic enable after power on. Singlechip control process: system power on, the singlechip send a low level signal to servo IN2 signal, start servo and orientation back to the origin point A. carry out every time when starting up, it means wherever the origin position is, will be back to

Chapter 5 operation and adjustment


the fixed position before work. When servo position back to point A, the singlechip send two level signal to servo IN4 IN5 so as to control servo move from point A to point B, C, D and back to point A, complete a circulation. Every time start and trigger are done by IN2 signal. Rising edge effective.

This system has the characteristics of simple control, accurate positioning, and strong anti-interference ability. The run speed and precise position set by Pn97- Pn109. The parameters needed to be set as below:

parameter No.	parameter name	definition	Set value
Pn4	Control mode	0: position mode 1:internal position mode	1
Pn111	IN1 definition	Define as position trigger	18
Pn112	IN2 definition	Define as orientation start	21
Pn113	IN3 definition	Define internal mode selection 0	19
Pn114	IN4 definition	Define internal position 0	16
Pn115	IN5 definition	Define internal position 1	17
Pn116	IN6 definition	Define internal mode selection 1	20
Pn 97	Internal position 0 turns		Set relevant parameters according to the actual ABCD four coordinates
Pn 98	Internal position 0 pulse		
Pn 99	Internal position speed of 0 positioning		
Pn 100	Internal position 1 turns		
Pn 101	Internal position 1 pulse		
Pn 102	Internal position speed of 1positioning		
Pn 103	Internal position 2 turns		
Pn 104	Internal position 2 pulse		
Pn 105	Internal position speed of 2 positioning		

Pn 106	Internal position 3 turns	
Pn 107	Internal position 3 pulse	
Pn 108	Internal position speed of 3 positioning	
Pn 109	Acceleration and deceleration time constant of internal control	

### 5.5.2 internal speed application example



Internal speed and torque mix control application electric wiring diagram

As shown in the figure, according to this example, 8 kinds of internal speed control and 2 types of internal torque control can be realized. And can be switched to each other. IN1 IN2 and IN3 are internal speed switch signals. Internal speed value set by parameters Pn33- Pn40. IN4 IN5 are internal speed and torque mode switch signals. Internal torque value set by parameters Pn45- Pn46.



## Chapter 5 operation and adjustment

Servo relevant parameters set as below:

parameter No.	parameter name	definition	Set value
Pn4	Control mode	0: position mode 1: internal position mode	1
Pn95	Servo enable	0: external enable 1: force enable	1
Pn110	IN0 definition	Servo enable	1
Pn111	IN1 definition	Define as speed 0	5
Pn112	IN2 definition	Define as speed 1	6
Pn113	IN3 definition	Define as speed 2	7
Pn114	IN4 definition	Define internal selection mode 0	19
Pn115	IN5 definition	Define internal selection mode 1	20
Pn116	IN6 definition	Define as moment of force 1	13
Pn 33	Speed 1		Set relevant parameters according to the actual run speed and moment of force
Pn 34	Speed 2		
Pn 35	Speed 3		
Pn 36	Speed 4		
Pn 37	Speed 5		
Pn 38	Speed 6		

Pn 39	Speed 7		requirements
Pn 40	Speed 8		
Pn 45	Internal torque 1		
Pn 46	Internal torque 2		

## 5.6 Servo features application

### Servo start orientation function

when input port set as servo start orientation function, only set input signal as ON, the orientation function will start automatically(except torque control mode). Rotate direction of orientation is determined by Pn 26. precise position of orientation is determined by Pn 24 Pn 25. if set single turn orientation, the precise position is determined by Pn 24; if set multi turns orientation, the precise position is determined by  $(Pn\ 25 * 131072) + Pn\ 24$ . when input signal OFF, orientation function turnoff.

#### 5.6.1 Position gear ratio switch function

When input port set as position gear ratio switch function, and input signal set as ON, the system use parameters of Pn 31 as present input pulse electronic gear. When input signal set as OFF, the system use the parameters of Pn9 as present input pulse electronic gear. This function mainly used to the occasions that dynamic electronic gear ratio needed.

#### 5.6.2 Position gain switch function

When input port set as position gain switch function and input signal set as ON, the system use the parameters of Pn57 as present position loop control gain. When input signal set as OFF, the system use parameters of Pn5 as present position loop control gain. This function mainly used to the occasions that dynamic position gain needed.

#### 5.6.3 Input pulse command filter

In the practice industry application sit, there is much interference, the input pulse command may caused the servo counting error because of the external

## Chapter 5 operation and adjustment

interference. Therefore, affect the servo repositioning accuracy. Setting this filter can prevent the interference into the servo system. Improve the ability of anti-interference of the system.

The relationship of set value and the passable frequency as below:

Pn 82 set value	The maximum passable pulse frequency
1000	1MHZ
500	500KHZ
250	250KHZ
100	50KHZ

### 5.7 Simulation speed control mode

Input analog voltage signal by the CN6, and set PN4 to be 7, Servo work in analog speed. We can control the speed of motor by adjust the size of voltage.

### 5.8 Simulation torque control mode

Input analog voltage single by the CN6, and set PN4 to be 8. Servo work in analog torque. We can control the torque of motor by adjust the size of voltage.

### 5.9 Position and simulation speed hybrid control mode

Input analog voltage single by CN6, and set PN4 to be 9, pulse command input from the control port. Servo work in position and analog speed hybrid control mode. Can be realized the switch between position and analog speed by I/O port control. Typical applications such as machine main axis.

### 5.10 Position and simulation torque hybrid control mode

Input analog voltage single by CN6, and set PN4 to be 10, pulse command input from the control port. Servo work in position and analog torque hybrid control mode. Can be realized the switch between position and analog torque by I/O port control. Typical applications such as: Injection molding machine, screw machine.

## Chapter 6 RS485 communication


### 6.1. RS485 communication hardware interface

6.1.1 This servo drive added RS485 communication function; it can drive servo system, change parameters, monitoring servo system status etc. So as to adapt to specific application.


### 6.1.2 External connection diagram

#### External thumbnails

#### HMI/PLC controller



### 6.1.3 Several external connection diagrams:



## Chapter 6 RS485 communication

### 6.2 Communication protocol

This servo system uses a standard asynchronous serial master-slave MODBUS communication protocol. Only one device host in the network can establish a protocol. Other device slaves can respond to the host's commands only by providing data or perform corresponding actions according to the host's commands. The host computer refers to a personal computer, an industrial control device or a PLC, etc. The slave refers to the servo system.

When the transmitting equipment(host) send communication command to the receiving equipment(device), the device which conform to corresponding address code receive the communication command and read message according to function code and relevant requirements. If CRC verify is correct, carry out the corresponding tasks and send the execution result (data) to the host. The returned information include address code, function code, execution data and CRC verify code. If CRC verify error, there will be no return information.

Communication form structure use RTU mode

#### 6.2.1 Communication code and data description

Function code	definition	operation (binary system)
03	Read register data	Read one or several register data
06	Write one way register	Write the binary system data in single register
10	Write multichannel register	Write the binary system data in multi- register

#### 6.2.2 Function code“03”: read multiplex register input

For example: host read address is 01, initial address is 3 device register data of 0116.

Bdevice (PDM) data register address and data is:

Register address	Register data (hexadecimal)	Corresponding PDM electricity
0116	1784	UA
0117	1780	UB
0118	178A	UC

## Chapter 6 RS485 communication

Message format sent by host:

Host send	bytes number	Sent message	remark
bdevice address	1	01	Send to the device which the address is 01
Function code	1	03	Read register
Initial address	2	0116	Initial address is 0116
Data length	3	0003	Read 3 registers (total 6 bytes)
CRC code	2	E5F3	Get CRC code from the host

Bdevice (PDM) response the returned message format

Bdevice response	bytes number	Returned message	remark
Bdevice address	1	01	From bdevice 01
Function code	1	03	Read register
Read data	1	06	3 registers total 6 bytes
Register data 1	2	1784	Address is 0116 memory content
Register data 2	2	1780	Address is 0117 memory content
Register data 3	2	178A	Address is 0118 memory content
CRC code	2	5847	Get CRC code from the bdevice

### 6.2.3 function code“06”: write one way register

For example: The host wants to save the data 07D0 to the slave register with address 002C (the slave address code is 01). After the communication data is saved, the PDM table with the address 002C with the original stored information as below.

address	Original stored data (hexadecimal)
002C	04B0

Message format sent by host:

Host send	bytes number	Sent message	For example
Bdevice address	1	01	Send to the bdevice which address is 01

## Chapter 6 RS485 communication

Function code	1	06	Write one way register
Initial address	2	002C	Register address need to write in
Write in data	2	07D0	Corresponding new data
CRC code	2	4BAF	CRC code get from the host

bdevice(PDM) response to the returned message format:

Message format and data are exactly the same with those sent from host.

### 6.2.4 Function code“10”: write multi-channel register

The host using this function code to save multiple data into data memory of the PDM sheet Modbus communication protocol register is 16 bit( 2 bytes), and MSB first. Such PDM memory is 2 bytes. As the Modbus communication protocol allows to save maximum 60 registers each time, therefore, PDM is allowed to save maximum 60 data registers each time.

for example: the host want to save 0064, 0010 into bdevice memory with address 002C, 002D ( bdevice address code 01 ) . After the communication data is saved, the PDM table with the address 002C/002D with the original stored information as below.

address	Original stored data (hexadecimal)
002C	04B0
002D	1388

Message format send by host:

Host send	Bytes number	Send message	example
Bdevice address	1	01	send to bdevice 01
Function code	1	10	write multi-channel register
Initial address	2	002C	The register initial address needed to write in
Saved data bytes length	2	0002	Save data bytes length (total 2 bytes)
Saved data bytes length	1	04	Save data bytes length (total 4 bytes)
Save data 1	2	04B0	data address 002C
Save data 2	2	1388	data address 002D
CRC code	2	FC63	CRC code get from the host

bdevice (PDM) respond returned message format:

Bdevice response	Bytes number	Bytes number	example
Bdevice address	1	01	Come from bdevice 01
Function code	1	10	write multi-channel register
Initial address	2	002C	Initial address is 002C
Saved data bytes length	2	0002	Save 2 bytes length data
CRC code	2	8001	CRC code get from bdevice

### 6.2.5 error verify code (CRC verify) :

This host or bdevice can use check code to judge whether the received message is correct or not. Due to the electroic noise or other interference, the information may wrong during transmission, error verify code (CRC) can verify whether the information of the host or bdevice is correct in the process of transmission, the wrong data can be given up (whether send or receive), which increased the safety and efficiency of the system. MODBUS protocol CRC(redundancy cycle code) include 2 bytes, namely 16 bit binary number. CRC code calculated by transmitting equipment(host), place to the end of send information frame. The receive information equipment (bdevice) re-calculate the received CRC of the information, and compare the calculated CRC with the received CRC, if they are not consistent, then means wrong.

When doing CRC calculation, use only 8 data bits. start bit and stop bit, if there is a parity bit also including the parity bit, do not participate in the CRC calculation.

● CRC code calculation method is:

1. Preset a 16-bit register as hexadecimal FFFF (that is all 1); called this register as CRC register;
2. The first 8-bit binary data (ie, the first byte of the communication message frame) is XORed with the lower 8 bits of the 16-bit CRC register, and the result is placed in the CRC register.
3. Right shift the content of CRC register a bit (forward the low bit) use 0 fill the highest bit, and check the shift bit after the right shift;



## Chapter 6 RS485 communication

4. If the shift bit is 0: repeat the third step(right shift a bit again); if shift bit is 1: CRC register XORed with polynomial A001 (1010 0000 0000 0001) ;
5. Repeat step 3 and 4, until right shift 8 times, then, all the 8 bits data are processed entirely;
6. Repeat Step 2 to Step 5 to process the next byte of the communication information frame;
7. When calculated all the bytes of the communication frame according to above steps, exchange the high and low bytes get from 16-bits CRC register;
8. At last the result of CRC register content is: CRC code.

### 6.3 Communication error and data process:

When PDM table detected other errors except CRC code error, must return the information to the host, the highest bit of the function code is 1, the function code from bdevice return to the host is on the basis of the host function code add 128. The following code indicates that an unexpected error has occurred

PDM received information from the host with CRC error, will be ignored by PDM table.

PDM returned error code format as below (except CRC code)

Address code: 1 byte

Function code: 1 byte (the highest bit is 1)

Error code: 1 byte

CRC code: 2 bytes

PDM response and return below error code:

81. Illegal function code.

PDM table do not support the received function code.

82. Illegal data position

Specified data position beyond PDM table range.

83. Illegal data value

Received the host sending data values exceed the PDM corresponding data range.

### 6.4 SDD series drive debugging software description and usage


This servo debugging software is green software and does not require installation. After obtaining the software from the manufacturer and storing it on the computer, it can be run directly. To connect the computer with the servo driver, you must use the manufacturer's special debug communication cable model (CABLE02). Using other communication lines can result in damage to the drive or inability to communicate.

1. Double click BGD Servo get in the first interface. As following:



2. Click on the serial port Settings software will automatically identify COM port. Choosing baud rate accord to the drive settings. If don't match that will cause communication error. The default baud rate of software and drive is 9600. The station number is based on the driver setting. The driver model is selected the other parameters are default. Save the parameter and then click the “ ” button. Now this software and drive can be normal communication. Offline mode is used to check other information of the software without connect the drive.

## Chapter 6 RS485 communication



Serial port Settings interface

The screenshot shows the 'BGDServoSoft' application window. It features a toolbar with several icons and an 'Exit' button. Below the toolbar, there is a table with 19 rows, each representing a parameter (Pn0 to Pn18). Each row contains a checkbox, the parameter name, a numerical value, a range, another numerical value, and a dash.

Parameter	Value	Range	Value	Value
<input type="checkbox"/> 0 Pn0	168	0 ~ 300	168	-
<input type="checkbox"/> 1 Pn1	1	0 ~ 100	1	-
<input type="checkbox"/> 2 Pn2	147	0 ~ 32737	138	-
<input type="checkbox"/> 3 Pn3	0	0 ~ 20	0	-
<input type="checkbox"/> 4 Pn4	0	0 ~ 5	0	-
<input type="checkbox"/> 5 Pn5	200	1 ~ 65535	200	-
<input type="checkbox"/> 6 Pn6	0	0 ~ 100	0	-
<input type="checkbox"/> 7 Pn7	300	0 ~ 1200	300	-
<input type="checkbox"/> 8 Pn8	0	0 ~ 2	0	-
<input type="checkbox"/> 9 Pn9	8192	1 ~ 32767	8192	-
<input type="checkbox"/> 10 Pn10	625	1 ~ 32767	625	-
<input type="checkbox"/> 11 Pn11	0	0 ~ 1	0	-
<input type="checkbox"/> 12 Pn12	20	0 ~ 30000	20	-
<input type="checkbox"/> 13 Pn13	800	0 ~ 30000	800	-
<input type="checkbox"/> 14 Pn14	0	0 ~ 1	0	-
<input type="checkbox"/> 15 Pn15	0	0 ~ 200	0	0.1
<input type="checkbox"/> 16 Pn16	1	0 ~ 1	1	-
<input type="checkbox"/> 17 Pn17	90	5 ~ 2000	220	-
<input type="checkbox"/> 18 Pn18	65	1 ~ 1000	20	-

Parameter Settings interface

3. Click the parameter setting. This interface mainly used for viewing and modifying the drive parameters. It Can be modified individually or in batches. It's greatly improve the efficiency of derive debugging.

## Chapter 6 RS485 communication

Functional specifications:

Reading: Read the external parameter list file to the current computer software.


Save as: Save the parameter in current software as other files. Providing download.

Upload: Upload the parameter in servo drive to the software in computer.

Download: Download the parameter in software to the servo drive.

Each issued: Download the parameter in software to the servo drive. Single data processing.

Save: Saving the modify parameter in current software to EEPROM in servo drive directly.



### Running test interface

4. Running the test icon can make four-way acquisition of the motor speed, position, command position, torque and current to facilitate the debugging of the driver. For specific commands, please refer to the commands for use in the debug software. This manual is no longer discussed.

## Chapter 6 RS485 communication

### 6.5 Communication command example

RTU command: 03 read single or multiple register

06 write single register

10 write multiple registers

#### 6.5.1 application example:

Read multi-channel register (for example: read PN9 PN10 electronic gear ratio)

01 03 00 09 00 02 14 09

Station No. read command No.9 address 2 datas check bit

return

01 03 04 00 01 00 01 6A 33

Return result: 4 bytes, two parameters are 01 01. that is PN9 PN10=1

Write multi-channel register (for example: write PN9 PN10 electronic gear ratio)

01 10 00 09 00 02 04 00 05 00 04 22 07

Station write No. 9 2 datas 4 bytes data 5 and 4 check code

Number command address

return

01 10 00 09 00 02 91 CA

Return result: already wrote in 2 bytes parameters, check the drive, PN9=5 PN10=4

Read single register (like read current magnitude of the servo output, namely UN-I address is 148)

01 03 00 94 00 01 C5 E6

return : 01 03 02 00 03 F8 45 indicates the read data is 03 means 0.3A

For example: read present motor position UN-2 UN-3

01 03 00 8D 00 02 54 20

return : 01 03 01 F5 B1 00 03 D9 D9

F5B1=62897 0003=03

so, present position is 0362897

Read present motor absolute position

01 03 00 9A 00 02 E4 24

return: 01 03 04 C4 C8 00 03 06 FC

C4C8=50376 actual should X2 , therefore, it is 100753

## Chapter 6 RS485 communication

So, the present absolute position is: 03 100753

If read negative number of turns, the actual pulse number should be: read pulse number -65536 or read pulse number -256.

Communication control I/O

01 06 00 80 00 01 49 E2: use communication to control motor enable signal

01 06 00 04 00 02 49 CA: use communication modify PN4=2

Note:

① read monitoring menu address, mainly by 485 communication, let the upper computer to read, transmit the servo status to the upper computer.

② monitoring address: 140~160, the sequency is the same with original drive, only insert motor turns after 154, the absolute position do not display the lowest bit(display bit is not enough).

③ write input port IO48-IO54 address, used to control input point by communication.

Input port address is 128~134, export port address is 135/136/137.

④ communication port standard use SDE servo software to debug, or use computer serial debugging. If use a computer to debug, must use the convertor from USB transfer RS485 can then proceed.

### 6.5.2 servo system communicate address list

Communicate items	Communicate address	Read/write status
Servo parameters	0-00FFH	Can read and write
input port status	0080H-0086H	Can write only
output port status	0087H-0089H	Can read only
monitoring menu content	008CH-00A1H	Can read only

note:

1) if communication control input port status needed , should set PN121 to 1, otherwise, it is invalid.

2) Only 16 bits of information are displayed in the absolute position 009BH of the motor, and \*2 is required to read out the correct position information.

## Chapter 7 Alarm and processing

If the servo with failure in use, the display will show: Al—xx, For fault diagnosis, please operate according to the content of this chapter, get rid of the corresponding fault and can be put into use again.

### 7.1 Alarm list

alarm code	alarm name	alarm reason
AL-0	normal	
AL-1	overspeed	servo motor speed exceeds the set value
AL-2	main circuit overvoltage	main circuit voltage too high
AL-3	main circuit undervoltage	main circuit voltage too low
AL-4	Position out of tolerance	motor with deviation over parameter Pn13 setting value
AL-6	speed amplifier saturation	speed amplifier saturated a long time
AL-7	Positive and negative drive simultaneously disables the alarm	Drive forward inversion
AL-8	Position deviation counter overflow alarm	Command and position deviation is too large
AL-9	encoder abnormal	encoder with break line or short circuit
AL-11	excess current 1	IPM module output current is too large
AL-12	excess current 2	DSP detection current is too large
AL-13	excess load	servo output torque over the allowed value

AL-14	braking abnormal	braking circuit abnormal
AL-16	motor thermal overload	Motor overload long time
AL-19	Encoder status bit error	Motor encoder or encoder line is abnormal
AL-20	EPROM error	servo inside EEPROM read-write abnormal
AL-21	Motor model error (version V157)	The motor is not ours or the drive ID is wrong.
AL-24	CPLD error	CPLD communication is abnormal
AL-25	Code disc CRC check error	Servo drive does not match the motor
AL-31	Code disc CRC parity error	
AL-32	The code disk battery is dead	Motor code disk power supply is abnormal
AL-44	Code wheel power supply for low voltage	Code wheel power supply for low voltage
AL-45	Drive A/D error	A/D sampling result error
AL-46	Encoder battery is low	Encoder battery voltage is lower than 3.1V
AL-47	Code plate battery without voltage	Add battery
AL-48	Abnormal number of code laps in operation	Bad disk or low battery voltage



## 7.2 Alarm processing method

alarm code	alarm name	reason	disposal method
AL-1	overspeed	input command pulse frequency is too high	Set input command pulse correct
		input electronic gear ratio is too large	set Pn9 Pn10 parameter correct
		encoder zero point error	ask the factory to reset the encoder zero
		motor U、V、W lead connect wrong	confirm the wiring sequence
AL-2	main circuit overvoltage	input L1 L2 L3 power voltage higher than AC260V	reduce power voltage
		brake circuit capacity is not enough (Usually occur in the occasion that frequently and rapidly start and stop and the load inertia is large)	1.prolong control system acceleration and deceleration time 2.contact manufacturer to increase braking resistance capacity
AL-3	main circuit undervoltage	input L1 L2 L3 power voltage less than AC170V	find out the external reason of low voltage
		servo protection action	replace a new servo drive
AL-4	position error	operation, the motor does not turn any angle, immediately alarm	1.confirm UVW wire phase sequence correct or not 2.confirm if the input pulse frequency is too high 3.pulse electronics gear setting it too large, set parameter Pn9 Pn10 correctly
		alarm when rotating ( <b>input pulse abnormal</b> )	confirm input pulse frequency and width
		alarm when rotating ( <b>error detection range is too small</b> )	set parameter Pn13 larger
		alarm when rotating ( <b>position proportion gain is too small</b> )	increase position gain Pn5 set value
		alarm when rotating ( <b>lack of torque</b> )	higher power servo motor

AL-6	speed amplifier saturation	motor mechanically locked	check the load mechanical part
		the load is too large	1.decrease load, 2.change a higher power drive and motor
AL-7	Positive and negative drive simultaneously disables the alarm	Motor stuck	Check the cause of motor jam
		Drive positive inversion	Cancel the drive forward negation setting
AL-8	Position deviation count overflow alarm	1. The acceleration and deceleration time is too short and the load is too large; 2. The servo motor is abnormal; 3, poor grounding	1. Increase the drive acceleration and deceleration time; 2. Replace the motor; 3. Correct grounding;
AL-9	encoder failure	encoder wiring wrong or line break	check or change encoder wire
		the encoder cable is too long, lead to the encoder power voltage a little low	shorten the cable
AL-11	Over-current 1	grounding defective	grounding correctly
		motor insulation damaged	replace a new motor
		motor winding with short circuit	replace a new motor
		servo motor parameters do not match	Correctly set motor ID number Pn1
		deceleration time is too short	increase the upper computer acceleration and deceleration time
		current surge	1.decrease parameter Pn43 Pn5 value 2.increase parameter Pn64 value
		input pulse is not well-distributed	increase pulse smoothing parameter Pn15 value
servo protection action	replace a new servo drive		

AL-12	Over-current 2	motor insulation damaged	replace a new motor
		grounding defective	grounding correctly
		servo protection action	Replace a new servo drive
AL-13	excess load	servo output torque over the allowed value	1.mechanically locked or resistance is large, 2.motor type is not good, change to higher power drive and motor
AL-14	braking abnormal 1	servo protection action	Increase the external braking unit
		brake circuit capacity is not enough	1.increase acceleration/deceleration time constant 2.replace a larger power servo and motor
		main circuit power is too high	check the AC input power supply
AL-16	motor thermal overload	motor over load long time	replace servo drive
AL-19	Encoder status bit error	1. The motor encoder line is incorrect; 2. The motor encoder is abnormal;	1. connecte the motor encoder line correctly; 2. Replace the motor encoder;
AL-20	EEPRO Mabnormal	servo inside EEPROM read-write abnormal	replace servo drive
AL-21	Motor model error	1. The motor ID does not match; 2. The motor is not ours	1, change the drive corresponding motor ID; 2, consult the driver manufacturer to correctly set the motor parameters;
AL-24	Abnormal CPLD	CPLD communication is abnormal。	Replace the servo drive.
AL-25	encoder CRC check error	CRC check error Motor model does not match	Disturbance, check grounding or replace the motor

AL-31	Encoder CRC parity error	Parity error	Disturbance, check grounding or replace the motor
AL-32	The code disk battery is dead	The code disk battery is dead	Add code wheel power supply
AL-44	Code wheel power supply low voltage	Code wheel power supply low voltage	Replace the code disk power supply
AL-45	Drive A/D error	A/D sampling result error	Replace the servo drive
AL-46	Encoder battery is low	Encoder battery voltage is lower than 3.1V Remind users to replace the battery	This alarm appears when it is turned on, it cannot be enabled. If you need to continue using it, you can set PN87=0 to use. If it occurs during operation, only the alarm is not enabled, and it does not affect the use. This alarm replaces the battery and then re-powers it to clear itself.

AL-47	Code plate battery without voltage	Indicates that the battery is dead, and the lap data is incorrect when it is powered on.。	Need to run the code disc alarm clearing program to clear. PN87=0 does not check this alarm.
AL-48	Absolute value code lap error	Bad disk or low battery voltage	Need to run the code disc alarm clear program to clear or replace the encoder

Clear AL-48 method: PN4=4 PN95=1 PN0=788 In the F4 interface, press and hold the Enter key for 5 seconds, then power on again. If it is invalid, replace the motor encoder.

Clear AL-47 method: PN4=4 PN95=1 PN0=789 In the F4 interface, press and hold the Enter key for 5 seconds, then power on again. Then set pn87=1 and save it. If it is invalid, replace the motor encoder.

**Special explanation:** if the servo drive alarm, but after power on again, the alarm will disappear. Generally, it is considered that the servo drive outside parts with problem or the parameter adjusted improperly; please check the servo peripheral parts. For example: power voltage, controller, mechanical load, motor etc. if the peripheral parts without problem, please consult the manufacture about parameter adjustment.

If the alarm cannot clear after power on, please replace the servo drive and observe.

### 7.3 FAQ or exception handling in use

1、 No-load operation motor vibrate strongly or scream, load with noise or position error.

Handling method: confirm the servo drive PN 1 parameter whether match with the connected motor, set correct parameter based on table 7.2, then restore to factory value.

For example: the current motor is 60ST-M01330MEL

- 1) check table appendix A, and get the motor ID=1
- 2) operate drive, set PN0 to 0
- 3) set PN1 to motor ID number, that is PN1=1
- 4) operate drive and enter SN-DEF interface, press the ENTER key on the display panel for 2 seconds, when display DONE, indicates success.
- 5) turn off and power on again, done.

**2、 The motor run positional accuracy and the required accuracy deviation is very large but regular**

Handling method: Set position pulse electronic gear ratio correctly.

This servo system default 10000 pulses rotate a circle. If the upper computer requires 3000 pulses for motor to rotate a circle, need to set gear ratio to meet requirement.

It can be calculated by below format:

$$3000 * (PN9 / PN10) = 10000$$

Get PN9=10      PN10=3

### **3、 drive input, output signal level reversed**

1) Set parameter PN53 PN54 PN55 to set input/output suitable high level or low level so as to adapt to different input/output level requirement of the controller.

### **4、 upper computer pulse but motor not running**

Make sure PN4=0, check UN-12 monitoring value, if there is digital shows that means the drive received pulse, it indicates the control signal connection without problem. Please refer to method 1 to clear fault. If display F 0.0 it indicates the drive do not received pulse. Please refer to method 2 to clear fault .UN-12 display unit is KHZ , like display F150, it indicates the present drive received pulse frequency is 150KHZ.

#### **Method1:**

Set below two parameters: PN95=1 PN4=3 in F2 model performs JOG function. If the motor can rotate, it indicates the motor, the motor power line, encoder wire connected correct, there is no problem.

Check CN1 signal if with INH signal or CLE signal with ON or not. It can be found by check UN-16.

If the motor can not run, please do following inspection

1) Check the drive with enable motor or not, and turn the motor shaft by hand. If it can not be rotated, indicates the motor enable locked. If it can be rotated, indicates there is no enable, please check if CN1 input enable signal correct connected or not. If the enable signal do not need to control by the upper

## Chapter 7 Alarm and disposal

computer. CN1 input enable signal not connected, can set PN95=1, drive motor automatically enable locked.

- 2) Check if the power cable which between drive and motor connected correctly or not, and the socket loose or not. Drive output terminal U V W PE and motor U V W PE whether corresponding. Power cable U V W PE must be connected correctly, can not change the sequence randomly.
- 3) Please contact the factory technical personnel.


### **Method 2:**

- 1) Check the pulse amplitude input to drive, the standard is 5V. If the pulse amplitude is 12V, must series 1K resistance; if the pulse amplitude is 24K, must series 2K resistance. The drive input circuit will be burned if not series resistance according to the requirements. Lead to the servo can not receive pulse.
- 2) Confirm the pulse connection mode is correct, the connection mode: differential connection mode and single end connection mode. Specific see below chart





Chapter 7 Alarm and disposal

Typic application: numerical control system, motion



Typic application: PLC, SCM controller



**5、 The motor can only turn to one direction**

- 1) Confirm the input pulse type to drive, pulse and direction setting PN8=0; Double pulse setting PN8=1; A/B orthogonal pulse setting PN8=1, and confirm the drive model is SDxxx-D。
- 2) Observe UN-12 display state, upper computer send forward signal should display F xx. Reversal signal should display F - xx. If the upper computer send forward signal or reversal signal both display F xx or F - xx. Please check the direction signal SIGN from upper computer to drive.
- 3) Please contact the factory technical personnel.

## Chapter 7 Alarm and disposal

### **6、 high speed stop or from top to down does negative work, the drive display AL—3**

- 1) modify the upper computer deceleration time
- 2) reduce motor speed
- 3) small power drive access external braking resistance
- 4) medium high power drive please contact the factory technical personnel.

### **7、 there is no display when power on**

- 1) Confirm power connecting wire and input power
- 2) Please contact the factory technical personnel.

### **8、 Power on drive display “。 。 。 。 。 。 。 ” or “888888”**

- 1) the input power lack phase, check each phase power line
- 2) servo drive damaged by short circuit, and lead to servo drive damaged. The motor damage can be judged by rotate motor shaft under the no-load situation, rotate a circle, if the shaft is not smooth, can be concluded that the motor is damaged.

### **9、 Motor position is not accurate**

- 1) Irregular, check motor connection mechanical part
- 2) Regular, monitor and analyse UN-02 UN-03 UN-04 UN-05 can get results
- 3) Screening interference, the signal wire use shield wire and grounding, add magnetic coiling. Motor cable change to shield wire. Electronic control system wiring again, make the strong and weak electricity line separately. Install filter etc.


The effect of the servo monitoring menu in analysis and adjustment processes.

- 1) UN-01 motor speed observe the motor actual speed
- 2) UN-02 UN-03 The current position of the motor: used to observe the current position of the motor. It is represented by the number of pulses. For example, if the control takes a fixed trajectory, the displayed value should be the same when each

Chapter 7 Alarm and disposal


repeat operation is performed. Indicates accurate positioning each time.

- 3) UN-04 UN-05 Pulse command count, used to monitor whether the pulse from the host computer is accurate. For example, if the control traverses a fixed trajectory, the displayed value should be the same when it comes to the same position each time it repeats its operation, indicating that the pulse sent by the host computer is accurate.
- 4) UN-08 motor present torque, used to observe motor actual operate situation. If this value over 90 for a long time, means the current motor type is small.
- 5) UN-12 input pulse frequency, used to observe pulse frequency from upper computer and stability state
- 6) UN-17 input signal state, used to judge whether the input signal is normal
- 7) UN-18 output signal state, used to judge whether the output signal is normal
- 8) UN-23 input model voltage AD value, used to indicate the level of the input voltage, it's 2048 with no input.



Input terminal display

Light display ON, go out display OFF



Output terminal display

Light display ON, go out display OFF